


RELAY BOX / REMOTE CONTROL



■ The **relay box** is an polarity inverting gear that is placed between the power supply (battery + circuit breaker) and the drive unit. It inverts the rotation direction and therefore enables to furl in or out. the foil sections turn at constant speed. With the relay box a waterproof circuit breaker is also delivered in the standard kit and turns off the furling gear in case of overheating (due to a Genoa sheet not released for instance).

- Remote control :
 - wired (waterproof device)
 - radio version (pocket transmitter + receiver to be fixed underneath the top cover of the relay box).



Remote control	Model Ref.	Part number
Wired ①	EF470+600	56012000140
Radio version ② Pocket transmitter + receiver	EF470+600	56012000150